

## Wall Mount Bracket for Greenworks G40HT61 Hedge Trimmer

### What's Included

- Modular PETG bracket: 1 × base plate, 2 × hook arms
- Mounting screws
- Rawl plugs (wall anchors)

### Tools Required

- Drill with masonry bit (for brick/concrete walls)
- Screwdriver or drill driver
- Spirit level (optional)
- Pencil or marker

### Step-by-Step Guide

#### 1. Position the Base Plate

- Hold the base plate against the wall at your desired height.
- Use a spirit level for alignment if needed.
- Mark the screw hole positions with a pencil.

#### 2. Drill and Insert Wall Plugs

- Drill holes at the marked positions using a masonry bit.
- Insert rawl plugs flush with the wall surface.

#### 3. Secure the Base Plate

- Align the base plate with the plugs.
- Drive screws through the plate into the plugs.
- Tighten until snug — avoid overtightening.

#### 4. Attach the Hook Arms

- Slide each hook arm into the base plate from above.
- They should slot in smoothly and firmly into place.